


USING DESCRIPTION

Thank you for buying this product. In order to use this product correctly, you must read this description carefully before using.


1. This product is suitable for
2. Must insure the operating environment within allowing range.
3. This product does not include tools



1. Arrange for a FAOC to assemble.




2. Insert screw cap into optical cable.



3. Fiber length.



4. Cut off the fiber at the length of 12mm using an optical fiber cleaver.



5. Insert optical cable into the fiber guide on the boot. When it is checked the bending of cable as above, stop inserting.



6. And maintaining the cable bending with right hand, push the connecting holder forward to the end and fix the fiber.



7. Take the boot cover down, connect the screw cap with boot by turning it and make the coating & strength member (yarn) fix.



8. Turn the protrusion of the housing toward the bottom and unite it to the body. Completion.

